

HS602 series

0,025% F.S

Part-No.	Pressure		Part-No.	Pressure	
	[bar]	[psi]		[bar]	[psi]
HS602-1	0-0,7	0-10,15	HS602-18	-0,1-0,1	-1,45-1,45
HS602-2	0-1	0-14,5	HS602-19	-0,4-0,4	-5,8-5,8
HS602-3	0-2	0-29	HS602-20	-1-1	-14,5-14,5
HS602-4	0-4	0-58	HS602-21	-1-0	-14,5-0
HS602-5	0-7	0-101,5	HS602-22	-1-2,5	-14,5-36,25
HS602-6	0-14	0-203	HS602-23	0-0,6	0-8,7
HS602-7	0-20	0-290	HS602-24	0-1,6	0-23
HS602-8	0-35	0-507	HS602-25	0-2,5	0-36
HS602-9	0-40	0-580	HS602-26	0-6	0-87
HS602-10	0-70	0-1015	HS602-27	0-10	0-145
HS602-11	0-140	0-2030	HS602-28	0-16	0-232
HS602-12	0-200	0-2900	HS602-29	0-25	0-362
HS602-13	0-350	0-5075	HS602-30	0-60	0-870
HS602-14	0-400	0-5800	HS602-31	0-100	0-1450
HS602-15	0-700	0-10150	HS602-32	0-160	0-2320
HS602-16	-0,025-0,025	-0,363-0,363	HS602-33	0-250	0-3620
HS602-17	-0,05-0,05	-0,725-0,725	HS602-34	0-600	0-8700